


## MADE IN THE U.S.A

## OPERATORS AND PARTS MANUAL MODEL - GAS GREENS ROLLER, HP5.5



#### MANUFACTURER OF OUTDOOR POWER EQUIPMENT

Products for Turf & Lawncare, Rental, Construction, Tree care, Wood Processing, Nursery & Farm Industries
Other Salsco Equipment

3-1/2" - 18", Gas, Diesel, and P.T.O, Wood/Brush Chippers Chipper Shredder Vacuums - Tailgate & Truckloader Vacuums Shaving Mills - Gas and Electric Greens Rollers

Quality of Workmanship, Innovative Design, Built to Last!

105 School House Road Cheshire, CT 06410 U.S.A. 800-872-5726, 203-271-1682, 203-271-2596 (Fax) sales@salsco.com, www.salsco.com

## **TABLE OF CONTENTS**

## **MODEL HP 5.5, GAS GREENS ROLLER**

COVER & TABLE OF CONTENTS	Pages $1-2$
STATEMENT OF FACT	Page 3
SPECIFICATIONS & FEATURES	Page 4
MACHINE REGISTRATION	Page 5
SAFETY & OPERATING INSTRUCTIONS	Page 6
SERVICE & MAINTENANCE INSTRUCTIONS	Page 7
PARTS DIAGRAMS	Pages 8 – 24
TORQUE CHARTS	Page 25
WARRANTY POLICY/PROCEDURE	Page 26
COPY OF WARRANTY CLAIM FORM	Page 27
COPY OF DEALER DELIVERY REPORT & WARRANTY CARD	Page 28
	1 age 20

SALSCO, INC. 105 School House Road Cheshire, CT 06410 800-872-5726, 203-271-1682 203-271-2596 (Fax) www.salsco.com, sales@salsco.com

#### **STATEMENT OF FACT**

You have just purchased the highest quality, most maneuverable, dependable, **GREENS ROLLER** on the market today. This unit has the ability to meet exact standards and perform for years with minimum downtime. HOWEVER, it cannot read nor will it understand this manual no matter how long you leave it on top of the machine.

It is your responsibility to read and understand this manual; it is also your responsibility to be certain this information is passed along to anyone who is expected to operate this equipment. Should you choose not to read, understand and pass along the information provided you, please expect equipment failure and possible injuries to persons around this equipment.

For the safety of the operator, it is **imperative** that this manual is carefully read and understood.

Once you have read this manual, it is your responsibility to be sure that all new operators read and understand this manual, especially all cautions stated.

As a manufacturer of equipment, we have a responsibility to design a safe piece of equipment. NOTE: The important safeguards and instructions in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors, which cannot be built into any product. These factors must be supplied by the person(s) caring for and operating this equipment.

#### **ONLY YOU CAN PREVENT ACCIDENTS!!**

## <u>SPECIFICATIONS AND FEATURES</u> GAS GREENS ROLLER - MODEL HP5.5

The Salsco Greens Roller is actually a multi-purpose tool, which, in a short time, has become a must-have for many golf courses. Our unit can be used on GREENS, WET OR DRY, and will increase speed an average of 1-2 feet. However, that's only part of the story. We can ROLL SOD, CLAY TENNIS COURTS, CART PATHS, SUB BASE FOR NEW GREENS CONSTRUCTION, WET GREENS, WET SPOTS ON FAIRWAYS, etc., etc. Because of traction and maneuverability this machine is ready and able when you are.

#### **Drive System**

A 13HP Honda Engine, electric start, powers this unit. Power is delivered to a Hydrostatic Pump through a love-joy coupling. Fluid power is then transmitted through 2,500 P.S.I. (10,000-lb. burst) hoses to drive motors. Drive motors change fluid power to mechanical power and transmit it through #50 chain to the rolls. ALL 5.5" diameter rolls are driven. This gives us the best traction in the roller business.

We want to smooth out the surface, not change it or compact it.

The Salsco Roller is very user friendly, with automotive type steering and smooth pedal controls. Operators spend very little time getting comfortable with this machine, usually before the first green is done.

The Salsco Greens Roller comes standard with its own trailer. When not in use with the Greens Roller, it can be used for many other tasks. An example would be for transporting greens mowers from green to green.

## **MACHINE REGISTRATION**

MANUFACTURED BY:	SALSCO, INC. 105 School House Rd., Cheshire, CT 06410 800-872-5726, 203-271-1682, 203-271-2596 (Fax) sales@salsco.com www.salsco.com
THIS MANUAL COVERS MODEL (s)	): MODEL HP5.5 - GAS GREENS ROLLER
	iscontinue, add improvements to, or change the design of thout obligation to improve existing machines, either by parts.
	ne policy of SALSCO to update existing machines at its own designs will be made in such a way that they can be "Retro
Record in the space provided below numbers for future reference.	the model and serial number of this unit. Please retain these
No parts orders will be accepted <b>WI</b> All part numbers are listed in this ma	THOUT MODEL NUMBERS OR PART NUMBERS. anual.
Serial Number	Model Number
NOTE: Be sure to complete your warranty claims.	arranty card. This will insure immediate processing of any
READ AND UNDERSTAND THE	S MANUAL REFORE STARTING MACHINE

#### SAFETY INSTRUCTIONS

- 1. **NEVER** leave unit running while unattended.
- 2. **NEVER** park on a green for any reason.
- 3. **NEVER** go down steep hills sideways. **ALWAYS** approach hills straight on.
- 4. **NEVER** change your mind mid-way down a steep incline. Once you've started down a steep incline, change direction only with the greatest of care and gentlest touch.
- 5. Allow engine to cool for several minutes before filling with fuel, since fuel tank is over the engine.

## NOTE: HONDA ENGINES - ALWAYS TURN OFF THE FUEL SHUTOFF, WHEN THE ENGINE IS NOT RUNNING, i.e. WHEN IN TRANSPORT, STORAGE, ETC.

#### **OPERATING INSTRUCTIONS**

- 1. Check that the unit has been serviced and all fluids are checked and topped off.
- 2. Check all hydraulic hose fittings.
- 3. Push fuel shut off switch to on position.
- 4. Push choke to full on position
- 5. Push throttle to just above idle.
- 6. Turn on/off switch to on position.
- 7. You should start engine from seat position. Just reach down to engine controls. Keep feet off pedals. Hydrostatic drive should come to neutral when engine starts.
- 8. Hydrostatic transmission should come to neutral when engine is started. REMEMBER: RIGHT PEDAL TO GO RIGHT, LEFT PEDAL TO GO LEFT.
- 9. Slide choke to full off position.
- 10. Once unit is running at just above idle, push pedal down slowly. Unit will begin to move. Drive it out of trailer on to grass area.
- 11. Since the unit is hydrostatic, engine should run at full R.P.M. and speed should be controlled by pressure on the pedal.


#### **HINTS:**


- 1. **KEEP BOTH FEET ON PEDALS AT ALL TIMES.** By keeping your heels planted and moving your toes to change direction, you have smooth control left to right.
- 2. If you roll the same direction as green was mowed, it's easy to follow the lines. This helps a new operator do a fine job sooner.
- 3. To insure longer life to your unit, when changing direction do so smoothly.


#### **SERVICE & MAINTENANCE INSTRUCTIONS**

- 1. Check all hydraulic hoses **DAILY**, **or before each scheduled use**, for wear and any signs of rubbing or chaffing. **REMINDER:** Drive motor hoses should be treated as wear items and should be replaced on a yearly basis.
- 2. Check all fittings for any signs of leaking **DAILY**, or before each scheduled use.
- 3. Check all grease fittings on a **WEEKLY** basis, and grease as necessary. (Add ½ shot of grease in all four bearings.)
- 4. Check engine to manufacturers' specifications and maintenance. USE CORRECT OIL. (Per Honda Manual).
- 5. Check hydraulic oil (use correct oil per decal).
- 6. Check Fuel NEVER fill a HOT engine.
- 7. Slide fuel shut off towards the engine. Always shut off the fuel when unit is NOT in use.
- 8. Slide choke away from engine till engine starts then turn choke off allowing engine to warm up.
- 9. When transporting unit from green to green be sure to turn off fuel.
- 10. **Oil & Filter Type** It has been determined that your Salsco machine will perform better by using a 25 micron filter. Salsco recommends using Mobil DTE 26 or Citgo HYD 68, non-detergent hydraulic oil, or their equivalents. The oil should have a viscosity rating of at least 100 SSU. While this is not a necessity, it will improve the overall performance of your machine. Salsco is now using this filter and hydraulic oil on all our machines using hydraulics.


SAFETY IS A PRIME CONCERN AT SALSCO AND THE SAFETY DECALS ON YOUR MACHINE ARE A HIGHLY VISIBLE AND CONSTANT REMINDER TO ALL OPERATORS. REPLACEMENT SAFETY DECALS MAY BE OBTAINED BY CALLING SALSCO @ 1-800-872-5726, OR THE DEALER IN YOUR AREA.







- 10 -




ISSUED: 05-06-2013 9 PART NO | QTY 0303016 0303015 0343003 0453117 0353106 0338060 DESCRIPTION CONE BEARING BEARING CUP FLAT WASHER O-RING, 3" ID WASHER JAM NUT

O:\Manuals\G.G.R. HP 5.5 restored\GGR\_HP5.5\_rev11.21.13.doc

GAS GREENS ROLLER MODEL HP5.5 - DWG #5


O:\Manuals\G.G.R. HP 5.5 restored\GGR\_HP5.5\_rev11.21.13.doc


GAS GREENS ROLLER - MODEL HP5.5 - DWG #6





GAS GREENS ROLLER - MODEL HP5.5- DWG #8


ISSUED: 05-06-2013 GAS GREENS ROLLER - MODEL HP5.5 - DWG #9 6 19 (3) (3) (<u>\$</u>) CV Q Z PART NO 0318048 0337033 0328059 0376250 0488045 0318023 0315375 0313004 0330218 0433209 16(STOCK) 0303019 0313003 0376319 0219488 0318022 0330223 0445172 0488046 0371411 0477231 0276771 0313081 0330222 0462462 040687 SWITCH. SNAP ACTION (NEUTRAL BRKT. SWITCH MOUNTG (NEUTR. RUBBER MOUNT, VIBRT DAMPG BRACKET, VIBRATION DAMPING SPACER, STL-3/8 ID x 5/8 0D x LINKAGE - RETURN TO NEUTRAL LEVER. HYD PUMP- EXTENDED SEAL KIT - HYDRAULIC PUIMP HYD FILTER ELEMENT ONLY ROD. FORWARD / REVERSE HYD FILTER & HOUSING PLATE, ENGINE MOUNT ENGINE, 13HP HONDA MOUNT. BATTERY BOX SUPPORT, HYD PUMP DESCRIPTION FUEL SCREEN FILTER BRACKET, OIL FILTER SPIDER COUPLING HUB. 17mm BORE HYDRAULIC PUIMP RUBBER MOUNT BELL HOUSING HUB. 1" BORE FRAME. BASE GAS CAP ROD END TEM 18 25 24 26 26 26 00 13 23 23





















Below is a quick reference chart for various "Flat Head Cap Screws" and the torque recommendations.

## **VALUES ARE STATED IN FOOT POUNDS**

BOLT SIZE	Thds Per Inch	SAE Grade 5	SAE Grade 8
1/4	20	10	14
	28		
5/16	18	19	29
	24		
3/8	16	33	47
	24		
7/16	14	54	78
	20		
1/2	13	78	119
	20		
9/16	12	114	169
	18		
5/8	11	154	230
	11		
3/4	10	257	380
	10		
7/8	9	382	600
	9		
1	8	587	700
	8		

#### Drive Belt Tension Measurement by Deflection



Deflection should be 3/8" when 8-12 lbs. push is applied at "B"

#### WARRANTY POLICY

Please remember to complete and return your Warranty Card and Dealer Delivery Report. Warranty Claims will not be considered if the Warranty Card and Dealer Delivery Report have not been returned to Salsco.

Your Salsco Commercial or Turf Equipment product is a commercial type product and is normally manufactured and sold for commercial or industrial use. Salsco will, for the original purchaser, for (5) years from the date of purchase (90 days if used for rental purposes) repair or replace, free of charge, any part or parts found to be defective in material, workmanship or both. Any transportation or shipping charges will be borne by the purchaser. If, during the warranty period stated above, the product does not function properly due to defect, simply contact Salsco and follow the Warranty Procedures included in this manual.

This warranty does not include:

- Incidental or consequential damages and is exclusive of any implied warranties.
- Normal maintenance parts, including, but not limited to hoses, chains, belts, filters, lubricants, etc.
- Parts or components, which are covered under the original manufacturer warranty, including, but not limited to engines, pumps, and motors.

#### WARRANTY PROCEDURE

In order for Salsco to consider your warranty claims in a timely manner you must follow the simple procedures listed below:

#### MACHINE OR PART FAILURE

- Call our service department for helpful instruction on how to correct or repair the problem. Preventive maintenance will also be suggested.
- b) When ordering parts for Warranty issues, you MUST retain possession of the old parts in question until notified with respect to returning the parts to Salsco or other disposition.
- Warranty Claims MUST be filed within 30-days from completion of the work performed. Contact our office for an electronic warranty claim form.
- d) Fill in all information requested on warranty claim form, a copy of which is included in this manual, (date of purchase, company name, address, etc.). List all parts used. Make sure part numbers are correct. You can obtain these from your manual. (include good description of problem; i.e. "leaking from spool" rather than "leaking").
- e) It is our goal to consider and reach a disposition on each Warranty Claim within 30-days from the date that it is received. Therefore it is important that you respond promptly to any request for further information. Claims with no response to inquiries will be closed as "denied for lack of response" 90-days from the date of request.
- f) Email, Fax or Send Warranty Claim form to our Warranty Department. **Warranty on parts most often requires return of the parts that were replaced.** DO NOT DISCARD OLD PARTS UNTIL YOU HAVE RECEIVED A DETERMINATION AS TO WHETHER THESE PARTS MUST BE RETURNED.
- g) Our Warranty Department will contact and instruct you on how to return the Parts to Salsco on an RA #. Returns MUST be made within 30-Days from issuance of RA #. FREIGHT CHARGES ON RETURN OF PARTS IS THE RESPONSIBILITY OF THE CUSTOMER. Normal pre-delivery adjustments are not covered under warranty. Labor Warranties are based on reasonable time allowances as determined by Salsco, Inc. and paid at 75% of posted labor rate. TRAVEL TIME IS NOT REIMBURSED UNDER THE WARRANTY POLICY.
- h) Be sure to put the RA form inside the box that you are shipping back, also be sure to put on the outside of the box "Return of Goods" and the RA #.
- i) Ship returns via a traceable method such as UPS Ground Service. Be sure that the shipment is insured for the appropriate value. If uninsured parts are lost, we cannot issue a credit.

#### PLEASE NOTE: Warranty forms should be filled out completely.

PREVENTIVE MAINTENANCE IS YOUR BEST INSURANCE AGAINST EQUIPMENT FAILURE. BE SURE TO READ THIS MANUAL, ESPECIALLY THE MAINTENANCE, OPERATING AND CAUTION SECTIONS.

SALSCO, INC., 105 School House Rd. Cheshire, CT 06410 800-872-5726, 203-271-1682 203-271-2596 (Fax) sales@salsco.com, www.salsco.com

#### WARRANTY CLAIM FORM

SALSCO, INC. 105 School House Rd. Cheshire, CT 06410 Phone:(203) 271-1682,(800) 872-5726 Fax: (203) 271-2596

Email: s.clark@salsco.com Website: www.salsco.com

END OWNER Date Submitted: Work Order #: Phone: Name: Office Use Only Fax: Email: Date Rec'd Address: Cust ID: Salsco WC Salsco RA Date Approved: PURCHASED FROM Date Rejected: Phone: Name: Fax: Processed By: Email: Dir. Del Report on File: YES NO Address: Warranty Card on File: YES NO Part(s) Total: Labor Total: Equipment/Warranty Information (Must be complete) Total Approved: Date Failed: Purchase Date: Invoice # Repair Date: Approved/Rejected: Model #: Serial #: Name: Reason for Rejection: Primary Use: Hrs Used: Warranty Claim/Work Order#: Was a Salsco Return Authorization # issued for repairs or Suggested Preventative Maint: Return of Parts? YES NO Probable Cause of Failure: Work Performed/Comments on Repair: Submitted By: Shop Labor Rate: Printed Name: Total Labor Hours to Repair: Parts Required for repair Price Each | Total Inv# Qty. Salsco Part #: Description: \$ \$ \$ S

Fill in all information requested on warranty claim form.

### INCOMPLETE FORMS CANNOT BE PROCESSED & WILL BE RETURNED

List all parts used. Make sure part numbers are correct. Any parts that you believe to be defective or any parts that break should be retained for possible inspection until after the warranty has been paid or part has been replaced.

# Salsco, Inc. 105 School House Rd.

MODEL.		SERIAL NO		
DEALER	СПУ		STATE	ZIP
PURCHASER (Lest Name or Company) (First Name) (Middle N	ADDRESS	CITY	STATE	ZIP
the undersigned dealer warrants that the above-descri- parefully inspected, adjusted and prepared for delivery be- purchaser; that both the operation and maintenance of explained to the purchaser; and that a copy of the Owner's were given to the purchaser and his attention called to Out experating instructions included in the manual and caution	fore delivery to the the machine were Instruction Manual r Warranty and any	The undersigned purchase above-described machine is a copy of the Owners's Ins said Instruction Manual ar responsibility to explain and	ave been explained to him truction Manual and Our \ d Caution Notes. I also	; acknowledges receipt of Varranty Policy printed in understand that it is my
Date Dealer		Date Sion By	Purchaser	
Date Dealer Sign By		Sign By _	Purchaser	
		Sign By _ Phone		
Sign By		Sign By _ Phone		

SERIAL#		MODEL NO.	
SAL	SCO LIMITED WARRANTY	CARD	
1. DATE PURCHASED:			
2. PURCHASER:			
3. PURCHASER ADDRESS:			
4. EMAIL ADDRESS:			
5. DEALER:			
6. DEALER ADDRESS:			
7. WILL THIS EQUIPMENT BE U	JSED COMMERCIALLY?	☐ YES	□ NO
8. DID DEALER SERVICE THIS	EQUIPMENT AND INSTRUCT	YOU IN ITS CARE A	ND
SAFE OPERATION ?		. □ YES	□ NO
9. DID YOU RECEIVE AN "OPE	RATION SERVICE MANUAL	AND SAFETY PAME	PHLET?
	en e	☐ YES	□ NO
NOTICE SI	GNED		
NOTICE		Purchaser	
IMPORTANT: THIS CARD MUST WITHIN 10 DAYS	FBE FILLED OUT COMPLETEL OF PURCHASE DATE, OR YOU		
VOIDED.			
WHITE - DEALER	YELLOW - OWNER	CARD - FACTOR	Υ

## **SERVICE RECORD**

If kept properly, this schedule will help track problems in the future.

					Total Hour
Date	Qty.	Part #	Description of Work Done	Hours Used	to Date
			The state of the s		
					***************************************
		·			
		······			
				<u> </u>	
				1	

MODEL #	S/N	
	452	DATE PURCHASED: